

mikroProg™ for Stellaris®

mikroProg™ is a fast USB programmer with hardware Debugger support. Smart engineering allows mikroProg™ to support all Stellaris® ARM® Cortex™-M3 and Cortex™-M4 microcontrollers in a single programmer.



 **MikroElektronika**
DEVELOPMENT TOOLS | COMPILERS | BOOKS



TO OUR VALUED CUSTOMERS

I want to express my thanks to you for being interested in our products and for having confidence in MikroElektronika.

The primary aim of our company is to design and produce high quality electronic products and to constantly improve the performance thereof in order to better suit your needs.



Nebojsa Matic
General Manager

The Stellaris®, ARM® and Windows® logos and product names are trademarks of Texas Instruments®, ARM® Holdings and Microsoft® in the U.S.A. and other countries.

Table of Contents

Introduction to mikroProg™	4	6. Connection schematic examples	14
Key features	5	Connecting with X00 series	15
1. Driver installation	6	Connecting with 1000 series	16
step 1 - Start installation	7	Connecting with 2000 series	17
step 2 - Accept EULA	7	Connecting with 3000 series	18
step 3 - Installing the drivers	8	Connecting with 5000 series	19
step 4 - Finish installation	8	Connecting with 6000 series	20
2. Connecting to a PC	9	Connecting with 8000 series	21
3. mikroProg Suite™ for ARM® software	10	Connecting with 9000 series	22
4. Connecting with a target device	12	Connecting with LM4F230 Series	23
5. Connector Pinout	13		

Introduction to mikroProg™



mikroProg™ for Stellaris® is a fast programmer and hardware debugger. Smart engineering allows mikroProg™ to support all Stellaris® ARM® Cortex™-M3 and Cortex™-M4 devices in a single programmer! Outstanding performance, easy operation, elegant design and low price are its top features. It is supported in mikroElektronika ARM® compilers, as well as in other ARM® compilers.

Key features

- **Hardware Debugging**
- No need for firmware update
- New microcontrollers supported via latest version of **mikroProg Suite™** for **ARM®** software

What you see

- 01 Flat cable
- 02 USB MINIB connector
- 03 DATA transfer indication LED
- 04 ACTIVE indication LED
- 05 LINK indication LED
- 06 POWER indication LED



1. Driver installation



On-board mikroProg™ requires drivers in order to work. Drivers are located on the Product DVD that you received with the package:


`DVD://download/eng/software/development-tools/arm/stellaris/mikroprog/
mikroprog_stellaris_drivers_v100.zip`

When you locate the drivers, please extract files from the ZIP archive. Folder with extracted files contains folders with drivers for different operating systems. Depending on which operating system you use, choose adequate folder and open it.




In the opened folder you should be able to locate the driver setup file. Double click the setup file to begin installation of the programmer drivers.

NOTE: Make sure to disconnect mikroProg™ before installing drivers.




step 1 - Start installation




- 01 In welcome screen click the **Next>** button

step 2 - Accept EULA



- 02 In order to proceed select **I accept the this EULA** (End User License Agreement)
- 03 Click the **Next>** button

step 3 - Installing the drivers



04 Drivers are installed automatically

step 4 - Finish installation




05 Click the **Finish** button to end installation process

2. Connecting to a PC



After driver installation is complete, you can now connect the programmer with your PC using USB cable provided with the package. Green **POWER LED** should turn ON, indicating the presence of power supply. Amber-colored **LINK LED** will turn ON when link between mikroProg™ and PC is established. Link can be established only when correct drivers are installed on your PC.

3. mikroProg Suite™ for ARM® software



mikroProg™ for Stellaris® programmer requires special programming software called mikroProg Suite™ for ARM®. This software is used for programming ALL of Stellaris® ARM® Cortex-M3™ and Cortex-M4™ microcontroller families. It features intuitive interface and SingleClick™ programming technology. Software installation comes on a Product DVD:



DVD://download/eng/software/development-tools/arm/stellaris/mikroprog/mikroprog_suite_for_arm_v110.zip

After downloading, extract the package and double click the executable setup file, to start installation.




Figure 3-1:
mikroProg Suite™ for ARM®
window


Software installation wizard




01 Start Installation




02 Accept EULA and continue




03 Install for all users



04 Choose destination folder



05 Installation in progress



06 Finish installation

4. Connecting with a target device




Figure 4-1:
IDC10 JTAG
connector

For connection with a target device mikroProg™ uses IDC10 JTAG connector, as shown on **Figure 4-1**. In order to make proper connection with the target board it is necessary to pay attention to IDC10 connector pinout. Every pin has a different purpose and for easy orientation IDC10 connector is marked with a little knob and incision between pins number 9 and 7, **Figure 5-1**.

5. Connector Pinout

- 01 **VCC-3.3V** - MCU power supply
- 03 **GND** - Ground
- 05 **GND** - Ground
- 07 **N/C** - Not Connected
- 09 **GND** - Ground

- 02 **TMS** - Mode Select
- 04 **TCK** - Clock
- 06 **TDO** - Data output
- 08 **TDI** - Data input
- 10 **SRSTn** - System Reset

JTAG programming/
debugging lines





Figure 5-1: Female connector pinout

6. Connection schematic examples



Following examples demonstrate connections with some of the most popular supported microcontrollers. Each one is carefully selected as a representative of the entire family. All MCUs use TMS, TCK, TDO, TDI and SRSTn lines for programming. These lines are located on same microcontroller pins within a family.




Figure 6-1: Connection schematics for 48-pin LM3S817 MCU via 2x5 male header




Figure 6-2: Connection schematics for 100-pin LM3S1538 MCU via 2x5 male header




Figure 6-3: Connection schematics for 100-pin LM3S2B93 MCU via 2x5 male header




Figure 6-4: Connection schematics for 100-pin LM3S3749 MCU via 2x5 male header




Figure 6-6: Connection schematics for 100-pin LM3S6537 MCU via 2x5 male header






Figure 6-8: Connection schematics for 100-pin LM3S9B96 MCU via 2x5 male header



Notes:

Notes:



Notes:

DISCLAIMER

All the products owned by MikroElektronika are protected by copyright law and international copyright treaty. Therefore, this manual is to be treated as any other copyright material. No part of this manual, including product and software described herein, may be reproduced, stored in a retrieval system, translated or transmitted in any form or by any means, without the prior written permission of MikroElektronika. The manual PDF edition can be printed for private or local use, but not for distribution. Any modification of this manual is prohibited.

MikroElektronika provides this manual 'as is' without warranty of any kind, either expressed or implied, including, but not limited to, the implied warranties or conditions of merchantability or fitness for a particular purpose.

MikroElektronika shall assume no responsibility or liability for any errors, omissions and inaccuracies that may appear in this manual. In no event shall MikroElektronika, its directors, officers, employees or distributors be liable for any indirect, specific, incidental or consequential damages (including damages for loss of business profits and business information, business interruption or any other pecuniary loss) arising out of the use of this manual or product, even if MikroElektronika has been advised of the possibility of such damages. MikroElektronika reserves the right to change information contained in this manual at any time without prior notice, if necessary.

HIGH RISK ACTIVITIES

The products of MikroElektronika are not fault - tolerant nor designed, manufactured or intended for use or resale as on - line control equipment in hazardous environments requiring fail - safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines or weapons systems in which the failure of Software could lead directly to death, personal injury or severe physical or environmental damage ('High Risk Activities'). MikroElektronika and its suppliers specifically disclaim any expressed or implied warranty of fitness for High Risk Activities.


TRADEMARKS

The MikroElektronika name and logo, the MikroElektronika logo, mikroC™, mikroBasic™, mikroPascal™, mikroProg™, EasyMx PRO™ and mikromedia™ are trademarks of MikroElektronika. All other trademarks mentioned herein are property of their respective companies.

All other product and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are only used for identification or explanation and to the owners' benefit, with no intent to infringe.

Copyright © MikroElektronika, 2012, All Rights Reserved.

mikroProg™ for Stellaris®



If you want to learn more about our products, please visit our website at www.mikroe.com

If you are experiencing some problems with any of our products or just need additional information, please place your ticket at www.mikroe.com/esupport

If you have any questions, comments or business proposals, do not hesitate to contact us at office@mikroe.com

mikroProg for Stellaris User Manual
ver. 1.00

