

Packaging Specification Sub D housing

1. SCOPE : TRAY PACKAGING FOR SUB D HOUSING WITH TYCO LABEL

2. USED PACKAGING PHANTOM NUMBERS AND QUANTITIES

Product	Packaging Phantom Number	UNIT QTY	Shipper QTY
Housing for 9 way connector	1-1392022-1	25	125
Housing for 15 way connector	1-1392022-2	25	125
Housing for 25 way connector	1-1392022-3	15	75
Housing for 37 way connector	1-1392022-4	15	60
Housing for 50 way connector	1-1392022-4	15	60

3. PACKAGING COMPOSITION

Composition of 1-1392022-1

Packaging material PNR	Description	Quantity
1485058-1	Cover (F42048V7201C 10)	5
1485057-1	Tray (F42048V7201C 11)	5
1392029-4	Box (F42048V7126C 4)	1
999639-1	Licence tag Label	1
1392095-1	Label (for tray)	5

Composition of 1-1392022-2

Packaging material PNR	Description	Quantity
1485058-2	Cover (F42048V7201C 12)	5
1485057-2	Tray (F42048V7201C 13)	5
1392029-4	Box (F42048V7126C 4)	1
999639-1	Licence tag Label	1
1392095-1	Label (for tray)	5

Composition of 1-1392022-3

Packaging material PNR	Description	Quantity
1485056-1	Cover (F42048V7201C 14)	5
1485055-1	Tray (F42048V7201C 15)	5
1392029-4	Box (F42048V7126C 4)	1
999639-1	Licence tag Label	1
1392095-1	Label (for tray)	5

DR. Van Reybrouck

DATE 10/07/01

APVD. Van Reybrouck

EC-SR10-10/07/01

DATE 10/07/01

Composition of 1-1392022-4

Packaging material PNR	Description	Quantity
1485056-2	Cover (F42048V7201C 16)	4
1485055-2	Tray (F42048V7201C 16)	4
1392029-4	Box (F42048V7126C 4)	1
999639-1	Licence tag Label	1
1392095-1	Label (for tray)	4

4. PACKAGING METHOD

- Pack the components in the tray.
- Put a label 1392095-1 into the tray. Printed side must be visible.
- Close the tray with the cover. Take care of the right orientation of the cover.
- Close bottom side of the box with transparant PP-tape.
- Insert the right quantity of filled trays into the box.
- Close the top side of the box with transparant PP-tape.
- Put a label 999639-1 on the short side of the box, in the upper right corner.
- When palletizing the boxes , keep the labels visible.