

Power Supply Mounting Plate

Index

Series	Model	Type A	Type B	Type L	DIN Rail
HMS	HMS50	A-29	-	L-31	DIN-02A
	HMS80	A-30	-	L-32	DIN-03
	HMS100	A-30	-	L-32	DIN-03
	HMS150	A-31	-	L-32	DIN-03
HWS-A	HWS15A	A-28	-	L-30	DIN-01A
	HWS30A	A-28	-	L-30	DIN-01A
	HWS50A	A-29	-	L-31	DIN-02A
	HWS80A	A-30	-	L-32	DIN-03
	HWS100A	A-30	-	L-32	DIN-03
	HWS150A	A-31	-	L-32	DIN-03
HWS	HWS300	-	-	L-33	-
	HWS600	-	-	L-34	-
	HWS1500	-	-	-	-
JWT	JWT75	-	-	-	L-DIN100/150
	JWT100	-	-	-	L-DIN100/150
MS	MS-9	-	-	-	-
	MS-10	A-12	-	L-03	-
	MS-11	A-13	-	L-04	-
	MS-12	A-14	-	L-05	-
	MS300	-	-	-	-
RWS-B	RWS50B	A-33	B-09	L-35	DIN-01A DIN-04
	RWS100B	A-34	B-10	L-36	DIN-02A DIN-05
	RWS150B	A-35	B-11	L-37	DIN-02A DIN-06
	RWS300B	A-36	B-12	L-38	DIN-07
	RWS600B	A-37	B-13	L-39	-
LS	LS25	-	-	-	LS-DIN-1
	LS35	-	-	-	LS-DIN-1
	LS50	-	-	-	LS-DIN-1
	LS75	-	-	-	LS-DIN-2
	LS100	-	-	-	LS-DIN-3
	LS150	-	-	-	LS-DIN-3

*Please check the model instruction manual for maximum allowable penetration and recommended torque for mounting screw.

*For more details, please refer to Technical Download Page.

https://product.tdk.com/info/en/products/power/tec_data/accessories_power_supply_mounting_plate.html