


CMM 100 / 200 female

STRAIGHT SMT

Part numbering :




nn = number of LF contacts

Calculation :


CMM 100	CMM 200
$A = (nn \times 2) - 2$	$A = nn - 2$
$B = A + 5$	$B = A + 5$

Refer to dimension table on cover page



CRIMP

Part numbering :



nn = number of LF contacts

Type	Gauge
S	24-28
C	22

Calculation :

CMM 100	CMM 200
$A = (nn \times 2) - 2$	$A = nn - 2$
$B = A + 5$	$B = A + 5$

Refer to dimension table on cover page

